

LIP-9030 and 9040C Button Layout



Button Guide

- Menu: access the settings for your phone, such as changing the font and display or changing the configuration.
- Directory: accesses the station, system and internal phone books.
- Mute: mute the call so that the caller cannot hear your voice
- 4. Speed: assign or use assigned speed dial numbers.
- 5. DND (Do-Not-Disturb): blocks incoming calls. You can also activate Do-Not-Disturb while the phone is ringing - this terminates the call and the caller will get a busy tone.
- Hold: place a call on hold the caller will receive onhold music or comfort music.
- 7. Transfer: transfer the current active call.
- 8. Message: access message box.
- Headset: if a headset is plugged in this button allows you to toggle between the headset and handset.
- Volume control: adjust the Ring, Headset, Handset, and Speaker volume.
- 11. **Speaker:** toggle the speakerphone On and Off during a call
- Soft keys: these buttons are interactive and have a changing function based on the phone's status.
- 13. Flex keys: a line, feature or quick dial can be assigned to these buttons.

Phone Directory

Press the **Directory** button followed by one of the following options:

Enter a minimum of 3 characters using the phone keypad (A = 2 + 1, B = 2 + 2 etc.)

Use the navigation key to select a number or a name and press OK.

Press Send.

Speed Dial (ALL):

Press the Speaker button.

Dial the desired **Speed Dial** number or * to call the last dialled number.

Voicemail

Access the stored

Accessing your Voicemail

Using the Phone Book Directory

telephone numbers in your system

Press the Voicemail softkey (if programmed) or press the Message button.

Select option 3 (Voicemail).

Enter Station Number followed by your Password.

Once you have accessed your voice mail box the following options are available;

Main Menu:

Press 1: New Messages

Press 2: Saved Messages

Press 8: Set personal greeting & password

Press #: Disconnect

Press 0: Operator

Press 9: Repeat options

Listening to Voicemail (Options)

New Message Menu (Based on pressing 1 from Main Menu)

Press 1: Mew Messages (Press 1 to replay message)

Press 2: Skip to next message

Press 3: Delete current message

Press 4: Forward message to another user

Press 5: Call back the person who left the message

Press 6: Skip the current message

Bearing With Cans	
Answering an Incoming Call	Lift the handset or press the PICKUP soft key. To answer a call on another extension that is programmed to one of the phones 10 flex keys, press the flashing flex key <i>before</i> lifting the handse
Making an External Call	Lift the handset and press a free flex key allocated to a line, or dial 9 to pick up an outside line. Once you have an outside line, dial your number.
Making an Internal Call	Lift the handset. Dial the extension number or press the flex key assigned to the contact.
Rejecting a Call	Press the DND button when a call comes in.
Placing a Call on Hold	Press the Hold button. To reconnect the call, press the Green flashing flex key.
Parking a call	
Parking a Call	To park an active external call, press Transfer , dial the park code (i.e. #601 for Park 1), and hang up to return to idle. To retrieve a parked call from any handset, lift the handset and dial the park code. You can also use a flexkey labelled 'Park' so you don't need to dial a code e.g. 601.
Camp On (Call Waiting)	When dialling an extension that is engaged, the Camp On feature allows the station to be notified that there is a call waiting. Press * to wait off-hook or Message to request a call back.
Transferring a call	
Transferring a Call	During an active call, press either the Transfer button or the TRANS soft key. Dial the extension number, external number or press the programmed flex key. Either speak to the recipient to announce the call, or simply hang up to complete the call transfer.
Returning to Caller from a Transfer	Press the Green flashing flex key.
Redialling a number	
Call Log List of phone numbers called and received	Press the LOG soft key. Scroll through the list using the Navigation buttons. To redial a number press the SEND soft key. To find out information on the call press the DETAIL soft key. Press BACK to exit.
Features	
Do-Not-Disturb Makes your extension unavailable	Press the DND key to activate. Press the DND key again to deactivate. Please note that this is not available on the attendant handset.
Conference Calls 3 way calling	To call the first party, follow "Making an External/internal Call" above for instructions. Once connected press the CONF soft key once. Call the second party (as above). Once connected, press the CONF soft key twice to connect the calls.
Ad Hoc Conference Calls 3 way calling Programming Call Forward (Routes your calls to another extension/group/speed dial) All these features will override	Press Speaker button Press Forward soft key Press 1: Unconditional Press 2: Busy Press 3: No-Answer Press 5: Off-Net Call Forward Press 0: Remote Forward
your voicemail functions. The content of this document is subject to revision without not	Dial the Extension/Group/Speed Dial/Phone Number Disable a forward by pressing the Speaker button then pressing the Forward soft key, following by pressing the # key. ce due to continued progress in methodology, design and manufacturing. IPECS is an Ericsson-LG Brand





Dealing with calls