## Ericsson-LG Enterprise iPECS LIP-9010 Handset Key Features Guide



## LIP-9010 Button Layout



## **Button Guide**

- Menu: access the settings for your phone, such as changing the font and display or changing the configuration.
- 2. **Transfer:** transfer the current active call or access the Program menu while the phone is idle.
- 3. **Directory:** accesses the private, public and internal phone books.
- 4. **Speed:** assign or use assigned speed dial numbers.
- DND (Do-Not-Disturb): blocks incoming calls. You can also activate Do-Not-Disturb while the phone is ringing - this terminates the call and the caller will get a busy tone.
- 6. **Message:** access your voicemail box.
- 7. **Hold:** place a call on hold the caller will receive on-hold music or comfort tones.
- 8. **Headset:** if a headset is plugged in this button allows you to toggle between the headset and handset.
- 9. **Mute:** mute the call so that the caller cannot hear your voice.
- **10. Speakerphone:** toggle the speakerphone On and Off during a call.
- 11. Volume control: adjust the Ring, Headset, Handset, and Speaker volume.
- 12. Call log: a list of calls received, dialed and missed.
- 13. Flex keys: A line, feature or quick dial can be assigned to these 5 programmable buttons.

## **Phone Directory**

Using the Dhane Book Directory	Us
Using the Phone Book Directory	
Access the stored telephone numbers in your system	

Press the **Directory** button followed by one of the following options: Enter a minimum of **3 characters** using the phone keypad (A = 2 + 1, B = 2 + 2 etc.) Use the navigation key to select a number or a name and press **OK** Press **Send** Speed Dial (ALL): Press the **Speaker** button

Dial the desired Speed Dial number or \* to call the last dialled number

Voicemail	
Accessing your Voicemail	Press the <b>Voicemail</b> softkey (if programmed) or press the <b>Message</b> button Select <b>option 3</b> (Voicemail) Enter <b>Station Number</b> followed by your <b>Password</b>
	Once you have accessed your voice mail box the following options are available;
	Main Menu:
	Press 1: New Messages
	Press 2: Saved Messages
	Press 8: Set personal greeting & password
	Press #: Disconnect
	Press 0: Operator
	Press 9: Repeat options
Listening to Voicemail (Options)	New Message Menu (Based on pressing 1 from Main Menu)
	Press 1: Mew Messages (Press 1 to replay message)
	Press 2: Skip to next message
	Press 3: Delete current message
	Press 4: Forward message to another user
	Press 5: Call back the person who left the message
	Press 6: Skip the current message

Dealing with calls	
Answering an Incoming Call	Lift the handset. To answer a call on another extension that is programmed to one of the phones 5 flex keys, press the flashing flex key <i>before</i> lifting the handset. You can also dial 566 to pick up any handset in your group, or dial *77 and the station number to pick up a handset that's not in your group.
Making an External Call	Lift the handset and press a free flex key allocated to a line, or dial 9 to pick up an outside line. Once you have an outside line, dial your number.
Making an Internal Call	Lift the handset. Dial the extension Number or press the flex key assigned to the contact.
Rejecting a Call	Press the <b>DND</b> button when a call comes in.
Placing a Call on Hold	Press the <b>DND</b> button when a call comes in.
Parking a call	
Parking a Call	To park an active external call, press <b>Transfer</b> , dial the park code (i.e. #601 for Park 1), and hang up. To retrieve a parked call, lift the handset from any handset and dial the park code.
Camp On (Call Waiting)	When dialling an extension that is engaged, the Camp On feature allows the station to be notified that there is a call waiting. Press * to wait off-hook or <b>Message</b> to request a call back.
Transferring a call	
Transferring a Call	During an active call, press the <b>Transfer</b> button. Dial the extension number, external number or press the programmed flex key. Either speak to the recipient to announce the call, or simply hang up to complete the call transfer.
Returning to Caller from a Transfer	If you are unable to transfer the call, press the Green flashing flex key to return to the caller.
Redialling a number	
Call Log	Press the <b>right</b> navigation button. Scroll through the list using the <b>Navigation</b> buttons. To redial a number press the <b>OK</b> button.
Features	
<b>Do-Not-Disturb</b> Makes your extension unavailable	Press the <b>DND</b> key to activate. Press the <b>DND</b> key again to deactivate. Please note that this is not available on the attendant handset.
Ad Hoc Conference Calls 3 way calling	To call the first party, follow "Making an External/internal Call" above for instructions. Once connected press the pre-programmed <b>CONF</b> flex key* once. Call the second party (as above). Once connected, press the <b>CONF</b> flex key twice to connect the calls. *To program a flex key, press <b>Transfer</b> then the key you wish to assign, dial 91 and then press <b>OK</b> .
Programming Call Forward (Routes your calls to another extension/group/speed dial) All these features will override your voicemail functions.	Press Speaker button Press Forward soft key Press 1: Unconditional Press 2: Busy Press 3: No-Answer Press 5: Off-Net Call Forward Press 0: Remote Forward Dial the Extension/Group/Speed Dial/Phone Number Disable a forward by pressing the Speaker button then pressing the Forward soft key, following by pressing the # key

The content of this document is subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson-LG Enterprise shall have no liability for any error or damage of any kind resulting from the use of this document © Ericsson-LG Enterprise Co., Ltd. 2019 Version 1.0 Ericsson-LG Enterprise Co., Ltd. (431-749) 77, Heungan-daero 81 beon-gil, Dongan-gu, Anyang-si, Gyeonggi-do, South Korea www.ericssonlg-enterprise.com | www.iPECS.com

